NEWTON SCIENTIFIC

M54 50kV 4W X-ray Source

light weight and compact design - only 365 grams



Model M54: 50 kV, 4W X-ray Monoblock - The M54 x-ray monoblock is a fully integrated miniature 50 kV, 4W x-ray generator designed specifically to be used as component of a handheld, portable, or benchtop x-ray instrument. The source includes a miniature sealed x-ray tube with a transmission-type end window, a high voltage power supply, and control electronics contained in a compact grounded enclosure.

Features

Compact design – ideal for handheld, portable and benchtop instruments

Low power consumption – compatible with battery operation

Easy to operate - analog control interface

Integrated design – no high voltage cables

Machined metal enclosure - precision mounting and alignment

Patented X-ray Omnishield™ – 360 degree light weight radiation shielding

Wide cone angle – 110 degree full width x-ray cone angle

Threaded adapter for collimated applications – optional

Applications

XRF Materials Analysis

- Alloy and metal sorting
- ROHS and ELV compliance
- Environmental analysis
- Forensic science
- Mining and geology
- Art and archeology
- Coating thickness
- Lead detection
- Quality control
- Precious metal verification

X-ray Imaging

- Medical, dental, small animal
- NDT
- · Security, contraband

Specifications

Tube type: Metal-ceramic Tube voltage: 5 kV - 50 kV 0 - 200 μΑ Tube current: Tube power: 4 watts maximum Cathode type: Tungsten filament Be, 125 µm X-ray window: Target type: Transmission Available targets: Au, Ag, Rh, W Depth to focal spot: 2.4 mm (see drawing) X-ray cone angle: 110° (see drawing) Input voltage: 5 - 12 VDC HV polarity: Grounded anode HV stability: < 0.1% Electrical insulation: Silicone potting Radiation shielding: Self-shielded

Operating temp (case): -10°C to 60°C Storage temp: -25°C to 85°C Cooling: Air cooled

Ambient humidity: 90% max (non-condensing)
Weight: Approx. 365 g.



Interface

PIN	NAME	TYPE	RANGE	SCALING / VALUE
Pin 1	V+	Input Power	5-12 VDC	
Pin 2	V+	Input Power	5-12 VDC	
Pin 3	GND	Ground	0V	
Pin 4	GND	Ground	OV	
Pin 5	TUBE I CONTROL	Analog Input	0-4V	0-200 μA (4W limit)
Pin 6	TUBE HV CONTROL	Analog Input	0-4V	0-50 kV
Pin 7	TUBE READY	Digital Output	TTL	LOW = NOT READY HIGH = READY
Pin 8	TUBE ENABLE	Digital Input	TTL	LOW = OFF HIGH = ENABLE
Pin 9	TUBE HV MONITOR	Analog Output	0-4V	0-50 kV
Pin 10	TUBE I MONITOR	Analog Output	0-4V	0-200 μΑ

NEWTON SCIENTIFIC

